

# RPS ZR-1 TOB Instructions



1. Replace ZR-1 Internal Slave with C6 ZO6 Unit



2. Remove clip.



3. Clip removed.



4. Remove stock piston.



5 & 6. RPS piston does not fit without grinding the small metal tabs away. 7. Finished



8. Inside of dust boot.



9. Install brown ring first.



10. Install metal ring.



11. Install spring. 12,13,14. Install RPS piston and push down on spring. Re-install retaining clip and tap



**RPS CLUTCHES**  
9810 Owensmouth Ave #11  
Chatsworth, CA 91311

818-993-9174  
[www.turboclutch.com](http://www.turboclutch.com)



15 & 16. With your fingers push the end of the green boot back inside the stock TOB.